

## Hardware Wiring Guide

This document details the electrical connections between the ESP32 and the various health sensors.

### ⚠ Important Safety Notes

- **Voltage Warning:** The MAX30102 and DS18B20 operate on **3.3V**. Connecting them to 5V will cause permanent damage.
- **MQ-3 Heater:** The MQ-3 requires **5V (VIN)** to power its internal heater.
- **Common Ground:** Ensure all sensors share a common ground with the ESP32.

### 1. Summary Pinout Table

| Component | Component Pin | ESP32 Pin    | Logic Level   | Notes                    |
|-----------|---------------|--------------|---------------|--------------------------|
| MQ-3      | VCC           | VIN (5V)     | 5V            | Heater Power             |
| MQ-3      | A0            | GPIO 36 (VP) | 3.3V (Scaled) | Requires Voltage Divider |
| DS18B20   | VCC           | 3.3V         | 3.3V          |                          |
| DS18B20   | DATA          | GPIO 4       | 3.3V          | 4.7kΩ Pull-up required   |
| MAX30102  | VIN           | 3.3V         | 3.3V          |                          |
| MAX30102  | SDA           | GPIO 21      | 3.3V          | I2C Data                 |
| MAX30102  | SCL           | GPIO 22      | 3.3V          | I2C Clock                |

### 2. Component Detailed Wiring

#### MQ-3 Alcohol Sensor

The MQ-3 output ranges up to 5V. Since ESP32 pins are only 3.3V tolerant, a **voltage divider** is used.

- **VCC:** Connect to ESP32 VIN (5V).
- **GND:** Connect to ESP32 GND .
- **A0 (Analog):** Connect to the high side of the voltage divider.
- **Divider Setup:** 1. Place a **10kΩ resistor** between MQ-3 A0 and ESP32 GPIO 36 . 2. Place a **10kΩ resistor** between ESP32 GPIO 36 and GND . *This scales the ~5V signal down to ~2.5V.*

#### DS18B20 Temperature Sensor

- **VCC (Right Pin):** Connect to ESP32 3.3V .
- **GND (Left Pin):** Connect to ESP32 GND .
- **DATA (Middle Pin):** Connect to ESP32 GPIO 4 .
- **Pull-up Resistor:** Place a **4.7k $\Omega$  resistor** between the DATA pin and the 3.3V rail.

#### MAX30102 Pulse Oximeter

- **VIN:** Connect to ESP32 3.3V .
- **GND:** Connect to ESP32 GND .
- **SDA:** Connect to ESP32 GPIO 21 .
- **SCL:** Connect to ESP32 GPIO 22 .

### 3. Passive Components List

- **1 x 4.7k $\Omega$  Resistor:** Pull-up for DS18B20.
- **2 x 10k $\Omega$  Resistors:** Voltage divider for MQ-3 protection.
- **1 x 100uF Capacitor (Optional):** Placed across VIN and GND to suppress power spikes during WiFi initialization.